



FAULT CODE F345

- 1 Chassis Control Module
- 2 Axle Speed Sensor
- 3 Engine RPM Sensor

FAULT CODE F345 - AXLE SPEED SENSOR CIRCUIT FAILED WHILE TRACTOR MOVING**F345**

*Note: Refer to "Diagnostics Procedure Overview and Checklist" (page 3-2-1) and "Troubleshooting Checklist" (page 3-2-4) before performing the procedures on this fault code.

